

Order No.
81 01061

Amine Test

Standard Measuring Range : qualitative
Number of Strokes (n) : 1
Time for Measurement : app. 5 s
Standard Deviation : $\pm 30\%$
Colour Change : yellow \rightarrow blue

Ambient Operating Conditions

Temperature : 10 to 40 °C
Absolute Humidity : 3 to 15 mg H₂O / L

Reaction Principle

Amine + pH Indicator \rightarrow blue reaction product

Cross Sensitivity

The tube indicates basic reacting gases with different sensitivities.
It is impossible to differentiate between the basic gases.



SI 8-2001